

Supported Devices with rtl8812au-driver

<https://github.com/aircrack-ng/rtl8812au/tree/6fd304f910b5ced30e99bb2beefe9ec5b49db00a>

	USBDEVICE		PRODUCT INFO
RTL8812	0x0409	0x0408	RTL8812:* NEC - *
	0x0411	0x025D	RTL8812:* Buffalo - WI-U3-866D *
	0x04BB	0x0952	RTL8812:* I-O DATA - Edimax *
	0x050D	0x1106	RTL8812:* Belkin - sercomm *
	0x050D	0x1109	RTL8812:* Belkin F9L1109 - SerComm *
	0x0586	0x3426	RTL8812:* ZyXEL - *
	0x0789	0x016E	RTL8812:* Logitech - Edimax *
	0x07B8	0x8812	RTL8812:* Abocom - Abocom *
	0x0846	0x9051	RTL8812:* Netgear A6200 v2 *
	0x0B05	0x17D2	RTL8812:* ASUS - Edimax *
	0x0DF6	0x0074	RTL8812:* Sitecom - Edimax *
	0x0E66	0x0022	RTL8812:* HAWKING - Edimax *
	0x1058	0x0632	RTL8812:* WD - Cybertan *
	0x13B1	0x003F	RTL8812:* Linksys - WUSB6300 *
	0x148F	0x9097	RTL8812:* Amped Wireless ACA1 *
	0x1740	0x0100	RTL8812:* EnGenius - EnGenius *
	0x2001	0x330E	RTL8812:* D-Link - ALPHA *
	0x2001	0x3313	RTL8812:* D-Link - ALPHA *
	0x2001	0x3315	RTL8812:* D-Link - Cameo *
	0x2001	0x3316	RTL8812:* D-Link - Cameo *
	0x2019	0xAB30	RTL8812:* Planex - Abocom *
	0x20F4	0x805B	RTL8812:* TRENDnet - *
	0x2357	0x0101	RTL8812:* TP-Link - Archer T4U AC1200 *
	0x2357	0x0103	RTL8812:* TP-Link - T4UH *
	0x2357	0x010D	RTL8812:* TP-Link - Archer T4U AC1300 *
	0x2357	0x010E	RTL8812:* TP-Link - Archer T4UH AC1300 *
	0x2357	0x010F	RTL8812:* TP-Link - T4UHP *
	0x2357	0x0122	RTL8812:* TP-Link - T4UHP (other) *
	0x2604	0x0012	RTL8812:* Tenda U12 *
	0x7392	0xA822	RTL8812:* Edimax - Edimax *

	USBDEVICE		PRODUCT INFO
RTL8821	0x0411	0x0242	RTL8821:* ELECOM - WDC-433DU2H *
	0x0411	0x029B	RTL8821:* Buffalo - WI-U2-433DHP *
	0x04BB	0x0953	RTL8821:* I-O DATA - Edimax *
	0x056E	0x4007	RTL8821:* Elecom - WDC-433DU2HBK *
	0x056E	0x400E	RTL8821:* ELECOM - ELECOM *
	0x056E	0x400F	RTL8821:* ELECOM - ELECOM *
	0x0846	0x9052	RTL8821:* Netgear - A6100 *
	0x0E66	0x0023	RTL8821:* HAWKING - Edimax *
	0x2001	0x3314	RTL8821:* D-Link - Cameo *
	0x2001	0x3318	RTL8821:* D-Link - Cameo *
	0x2019	0xAB32	RTL8821:* Planex - GW-450S *
	0x2357	0x011E	RTL8821:* TP Link - T2U Nano *
	0x2357	0x011F	RTL8821:* TP-Link - Archer AC600 T2U Nano *
	0x2357	0x0120	RTL8821:* TP Link - T2U Plus *
	0x3823	0x6249	RTL8821:* Obihai - OBiWiFi *
	0x7392	0xA811	RTL8821:* Edimax - Edimax *
	0x7392	0xA812	RTL8821:* Edimax - EW-7811UTC *
	0x7392	0xA813	RTL8821:* Edimax - EW-7811UAC *
	0x7392	0xB611	RTL8821:* Edimax - EW-7811UCB *

	USBDEVICE		PRODUCT INFO
RTL8814A	0x0B05	0x1817	RTL8814A:* ASUS - ASUSTeK *
	0x0B05	0x1852	RTL8814A:* ASUS - ASUSTeK *
	0x0B05	0x1853	RTL8814A:* ASUS - ASUSTeK *
	0x056E	0x400B	RTL8814A:* ELECOM - ELECOM *
	0x056E	0x400D	RTL8814A:* ELECOM - ELECOM *
	0x0846	0x9054	RTL8814A:* Netgear A7000 *
	0x0E66	0x0026	RTL8814A:* Hawking Technologies - HW17ACU *
	0x2001	0x331A	RTL8814A:* D-Link - D-Link *
	0x20F4	0x809A	RTL8814A:* TRENDnet - TRENDnet *
	0x20F4	0x809B	RTL8814A:* TRENDnet TEW-809UB *
	0x2357	0x0106	RTL8814A:* TP-LINK Archer T9UH *
	0x7392	0xA834	RTL8814A:* Edimax - Edimax *
	0x7392	0xA833	RTL8814A:* Edimax - AC1750 *